



18375 Bandilier Circle, Fountain Valley, CA, 92708 Tel: 714 965-7828 Fax: 714 965-7829

**Radflo Suspension Technology Front Suspension
Install Instructions
2.5" Front Suspension Kit**

2003-2009 Toyota 4Runner, 2006-2010 Toyota FJ Cruiser, 2005+
Toyota Tacoma, 2002-2009 Prado 120, 2005-2011 Toyota Hilux

Note:

**Radflo Suspension Technology recommends that all products are installed
by trained professionals.**

List of contents:

- 2 Coilovers
- 4 lower coilover bolt spacers (tied to coilover shock)
- 6 upper coilover mount bolts and nuts with washers (tied to coilover shock)

Tools required:

- 10, 12,13,14,17,19 mm wrenches and socket set
- Torque wrench
- Tie-rod puller
- Pry bar & breaker bar
- Long nose pliers
- Metric allen wrenches
- 1/8" x 1" cotter pins – 2
- Professional lift or floor jack and 2 large jack stands



18375 Bandilier Circle, Fountain Valley, CA, 92708 Tel: 714 965-7828 Fax: 714 965-7829

Instructions

1. Once vehicle front is in the air (via professional lift or floor jack & jack stands on a flat surface) remove the 2 front wheels.

2. Remove the 4 bolts retaining the front skid plate. Then remove skid plate.



3. Remove the swaybar end link nut and swaybar link from the spindles on each side. Let the links hang loose from the spindle. **Tip:-** If the nut simply rotates the bolt on the ball joint, insert a metric allen wrench to the end of the bolt to hold it in place.



18375 Bandilier Circle, Fountain Valley, CA, 92708 Tel: 714 965-7828 Fax: 714 965-7829



4. Now undo the bolts holding the swaybar bushing brackets and then remove the swaybar from the vehicle. **Tip:-** The front 2 holes on the bracket are open allowing you to slide the bracket out. Thus remove the 2 bolts to the rear and then undo the 2 front, but don't remove. Then simple slide the bracket and swaybar out towards the rear.



5. Undo the cotter pin in the steering outer tie rod end and then remove the castle nut.





18375 Bandilier Circle, Fountain Valley, CA, 92708 Tel: 714 965-7828 Fax: 714 965-7829

6. Use a tie rod puller to separate the tie rod from the spindle. Be careful not to damage the rubber boot on the tie rod. Once separated move the steering link away from the spindle to allow more space to remove the strut assembly later.

7. Undo the lower bolt on the front strut, then remove the bolt. **Tip:-** Using a pry bar on the upper control arm and forcing down can help to make it easier to pull the bolt out.



8. Remove the 3 top bolts holding the strut assembly to the frame.



18375 Bandilier Circle, Fountain Valley, CA, 92708 Tel: 714 965-7828 Fax: 714 965-7829



9. Push down on the upper control arm with a pry bar while moving the strut out of the lower mount and down slightly. Then slide it out towards the front while releasing the pry bar and moving it out underneath the upper control arm.

10. Using the reverse of step 9 push in the new coilover assembly. Make sure the charge port faces away from the frame and towards the fender. **Tip:-** Only insert the rear bolt in the top plate of the coilover. Once the rear bolt is through the frame holes tighten it slightly and then insert the other 2 bolts and tighten the bolts.





18375 Bandilier Circle, Fountain Valley, CA, 92708 Tel: 714 965-7828 Fax: 714 965-7829

11. Tighten the top 3 bolts. Make sure to use the supplied washers. Hand tight only.
12. Push down on the upper control arm with a pry bar and slide the bottom of the coilover assembly in the lower strut bucket on the lower control arm. Make sure the supplied spacers are in the coilover lower heim joint (one on each side). **The longer spacer should be towards the front of the vehicle** to create more room for the swaybar.
13. Insert the lower bolt and tighten the nut. Reverse of step 7. Torque the lower bolt to **100 ft/lb**. Tip:- Push down on the upper control arm with a pry bar to make it easier to line up the coilover hole with the lower mount and bolt.
14. Insert the outer tie rod back into the spindle. Torque the castle nut to **67 ft/lb**. Insert a new cotter pin in the nut and tie rod, bend the end of the pin to hold it in place.





18375 Bandilier Circle, Fountain Valley, CA, 92708 Tel: 714 965-7828 Fax: 714 965-7829

15. Install swaybar spacers on the frame. Use stock bolts and install the spacer so the stock bolt heads go into the machine holes, and also that the new holes are towards the front of the vehicle, thus moving the swaybar mount point forward. Torque the swaybar bolts to **30 ft/lb.**



16. Install the swaybar and swaybar brackets on the spacers. Make sure that the swaybar ends push in above the CV axles on each side. Note the tip in step 4 and apply in reverse. Torque the swaybar spacer bolts to **30ft/lb.**





18375 Bandilier Circle, Fountain Valley, CA, 92708 Tel: 714 965-7828 Fax: 714 965-7829

17. Insert the swaybar end link bolts through the spindle holes. Reverse of step 3. Torque the nuts to **52 ft/lb**.
18. Install the front skid plate. Reverse of step 2. Only tighten the bolts hand tight with a wrench.
19. Install the wheels and torque the lug nuts to **85 ft/lb**.
20. Drive a small distance with the new coilovers to settle the suspension and then measure for the desired ride height.
21. The coilovers can be adjusted to provide the desired ride height if needed. Do not exceed 3.5" of lift over stock to avoid front suspension and alignment issues.
22. To adjust the coilovers both front wheels need to be drooped completely. There is no need to remove the wheels. Use a C-Spanner wrench (not supplied) to loosen the top lock collar of the adjustment ring. Using the C-Spanner wrench rotate the adjustment collar down for additional lift or up for less lift. The lift will be approximately double the distance the collar is moved. Once the desired lift is reached tighten the lock collar on the adjustment collar again. Tip:- Using some lubrication on the thread and collar will make it easier to adjust. **DO NOT adjust the collar beyond 1" of exposed thread between the top of the collar and the bottom of the top shock cap.**

Please retain all stock components if you ever have the need to remove your Radflo suspension products.

For technical support please contact Radflo Suspension Technology directly at (714) 965-7828 Monday - Friday 8:00 am - 5:00 pm Pacific time. Thank you for your purchase of Radflo Suspension Technology products.